SIMPLE PRINT PRO FLOW





PRINT WIZARD



Pick 'Environment' from the list

(711 White, for white garments or 711 Colour for coloured/black garments)




Image will show as a small thumbnail on the left, under composites.

Check you can see your full page. Use CRTL— on your keyboard, or use the magnifying glass tool on screen.

Drag your image from the left onto your page in the middle of the screen.

Use the Qrip box on the right hand side to resize and position your image on your page.

If Qrip is not open, go to View/Show > Qrip.

The top size selection is how it has opened.

The second will make the image fit to page, but may distort the proportions.

The third size selection option will allow you to enter values, use the up and down arrow keys and if the padlock box underneath is checked it will keep the proportion restraints on. (This tends to be the most used option)

Make sure that the box at the bottom of Qrip that says 'Mirror' is checked.

You can right click on the image and go to 'rotate', to turn the image.

| |

You can now click the button with the image of the printer, either at the top or on your Qrip box to print.







