

3.5.4 Confirming Default Settings

This section gives an overview of the Setup Menu and the M series default settings.

There are some critical M series default settings that ensure that the printer operates in accordance with the M series specifications. If these settings are not set at the correct value, the printer will not behave correctly.  [Table 3-2 Setup Menu Structure page 38](#)

 **CAUTION**

Take care not to alter the default settings of the printer. If it is necessary to enter the Setup Menu for any reason, follow the instructions below carefully and ensure that settings are maintained as described in  [3.5.4.4 "Setup Menu Structure" p.38](#)

3.5.4.1 Enter the Setup Menu


When the printer is in "normal" mode, press the [Menu\] key

- ✗ The operation panel will shift to the setup menu display and show "`*Menu* TestPlot>`".

3.5.4.2 Return to Normal Display

While the plotter is in setup menu display, if either of the following operation is done, the operation panel shifts to Normal display.


- ✗ [Menu] key on operation panel is pressed.
- ✗ In the Setup menu, leave the keys untouched for three minutes.



3.5.4.3 Menu Setup Procedure


Follow the following procedure to configure various setup menus.

1. Check that the operation panel is Normal (Display will read Ready to Plot or Paper End or End of Roll).
2. Press the [Menu] key on the operation panel.



- "*Menu* TestPlot>" will be displayed on the operation panel.
- The setup menu display will be displayed.

3. Press the [Back] key or [Next] key on the operation panel to select a setup item and press the [Enter] key.




- The settings will be confirmed.
- When setup item has a submenu, the submenu will be displayed.


NOTE

When a setup item has a submenu, [>] is displayed on the right end of the LCD monitor of the operation panel.

4. If a submenu item displayed on the LCD monitor of the operation panel is blinking, its setting can be changed.
Press the [Forward] key or [Reverse] key to change the setting.



5. To save the changed setting, press the [Enter] key on the operation panel.




- ✗ The setting will be saved and the next setup item will be displayed.

NOTE

If the [Cancel] key, [Forward] or [Reverse] key is pressed after changing a setting, without pressing [Enter] key, that setting will not be saved.

6. Press the [Menu] key or [Cancel] key on the operation panel to exit from the setup.



- × The previous setup menu will be displayed.
- × When the main menu is displayed, the screen turns to Normal.

3.5.4.4 Setup Menu Structure

The setup menu has the following items.

< > parts in each list are initial settings

[] parts in each list are M series default settings (if different from initial settings).

TABLE 3-2 SETUP MENU STRUCTURE

<i>Setup Menu Item</i>	<i>Setup Menu Sub Menu Item</i>	<i>Setup Menu Sub Menu Item / Setting Value</i>			
Test Plot Menu	SetupPlot				
	NozzleCheck				
	AdjustPlot				
	PalettePlot				
	Maintenance				
MediaSet Menu	Media	MonoTrac			
		Col.Trac			
		[Plain]	PF	ConfirmPrint	
				InitialChange	
				<InitialPrint>	
				MicroChange	
				MicroPrint	
		RollCut	[Off]	RollCut	
				On	
				RollCutMethod	
				<2steps>	
				3steps	
		<Coat>			
		Film			
		Photo			
		User1			
		User2			
		User3			
		User4			
CutSheetSize	CutSheetSize	Auto			
		<Vert.>			
		Hori.			
	TopFeed	<0mm> to 100mm			
	Manage Roll	<Invalid>			
		Roll1			
		Roll2			
		Roll3			
		Roll4			
Cut RollTop		<0mm> to 500mm			

Setup Menu Item	Setup Menu Sub Menu Item	Setup Menu Sub Menu Item / Setting Value
Command Menu	SHOULD NOT BE DISPLAYED	SET MENUMASK TO NORMAL
Pen SetupMenu	SHOULD NOT BE DISPLAYED	SET MENUMASK TO NORMAL
Layout Menu	Layout	On
		<Off>
	LayoutMethod	MAX-MIN
		<Command>
	Margin	<Normal>
		Full
	CutLine	On
		<Off>
	LayoutTimer	Off
		10s to <120s> to 800s
Network Menu	IPaddress	000.000.000.000 to <192.168.001.253> to 255.255.255.225
	SubnetMask	000.000.000.000 to <255.255.255.225> to 255.255.255.225
	Gateway	000.000.000.000 to <192.168.001.254> to 255.255.255.225
	BiDir Port	SHOULD NOT BE DISPLAYED SET MENUMASK TO NORMAL
	MACAddress	
Utility Menu	Menu Mask	<Normal>
		OFF
		AlwaysOFF
	Error Display	On
		<Off>
	Initial	Yes
		<Off>
	DataDump	Start/End
		All
	CutterChange	<No>
		Yes
	On Cleaning	On
		<Off>
	Prefeed	<Manual>
		Data
		Take-up
	PrefeedAmount	<0mm> to 3000mm

Setup Menu Item	Setup Menu Sub Menu Item	Setup Menu Sub Menu Item / Setting Value
Utility Menu	Effect	<None1>
		None2
		Wave1
		Wave2
		Fuzz1
		Fuzz2
		Wow1
		Wow2
		Fine & Wave1
		Fine & Wave2
AutoCL: Setup	Waiting Time	<0min> to 1440min
		<Short>
		Long
	PrintingTime	Normal
		<0min> to 180min
		<Short>
	PrintingKind	Long
		Normal
		BeforePrint
	BeforePrtKind	<Off>
		On
		<Short>
Consumption Menu	Spitting	Long
		Normal
	PassCount	-999cnt to 999cnt
Consumption Menu	Remain Roll	**m
	RemainCutterLif	0% to 100%