

## DTG BRIGHT INKS VERSION

Date: September 2020

### Pre-Treating and Curing

- 1 – Pre-treating 19 grams of pretreat over A3 sized area –
  - Pressed at 160-165 for 20-30 seconds
- 2 – Curing the print Pressing at 160 / 165c White garments –
  - 60 seconds low pressure Dark with white ink –
  - 90 seconds, low pressure
  - Use the same settings when utilizing a heat tunnel.

A wash and feasibility test must always be carried out prior to any production runs.

### Warning hazard statement

**Eye irritation prevention:** Wash hands thoroughly after handling products.

**Response:** IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists, get medical advice/attention.

**Inhalation:** If symptomatic, move to fresh air. Get medical attention if symptoms occur.

**Skin:** Wash off immediately with soap and plenty of water. Get medical attention if symptoms occur.

**Ingestion:** If swallowed, DO NOT induce vomiting, get medical attention if symptoms occur - Refer to Safety Data Sheet.