HOW TO STEP BY STEP' GUIDE



PRINTING CMYK CHANNEL AS A SPOT CHANNEL ONLY



Using the Print-Pro WIGA RIP we can print any of the individual CMYK channels as a separate spot channel.

The following instructions explain how to achieve this

Figure 1 shows an image where the criteria is to print this using only the K channel.





Figure 1 Simply open the image in your RIP software and place it on a white background template Now open the PRINT SETUP options and navigate to PROPERTIES












HOW TO 'STEP BY STEP' GUIDE



Now setup the black channel as "braille" and apply an ink strength of 100% and as "non transparent region"








HOW TO 'STEP BY STEP' GUIDE



Now navigate to layer selection and setup braille as layer 1, in case of printing onto a coloured background, white underbase would be layer 1 and braille as layer 2



You should now set any preferred resolutions and pass counts etc in DEVICE OPTION as per normal setup of any print job





